

K65 Protect - Quad Pod Padding

Instruction Manual

Additional player protection when locating the Quad Pod on run off areas for sports applications with space restrictions.



PRODUCT CODES: K65-PROTECT • K65-PROTECT360

www.riteliteportablelighting.co.uk



NOTE: The above shows the kit included with the K65 Protect 360. The standard kit is similar but only includes $2 \times \log p$ adding and $2 \times \log p$.

FITTING THE PADDING



1. Wheel the Quad Pod to the location it will be setup. Lower the Quad Pod legs and ensure the unit is stable.



2. If a cover is fitted ensure it is placed in its 'in-use' position at the rear of the Quad Pod and tie back.



3. Remove the wheels by removing the two pins.



4. Fold each leg pad to create a 'U' shape and fit the end caps with the velcro.



5. Place each leg pad over each leg ensuring the red pins are covered and the leg end cap protector is mounted up against the end of each leg. If you have the standard K65-PROTECT kit with padding for two legs, apply the leg pads over the two legs facing the playing area. If you have the K65-PROTECT360 kit all legs can be covered.





6. Secure to the leg using the $2 \times lower$ velcro strips provided underneath the legs. Secure the top velcro strip around the Quad Pod's tie bars. This ensures the padding is secure to the unit and cannot slide down the leg.



7. Offer one of the front/back pieces to one of the side pieces and secure using the velcro provided. Please ensure that the padding kit is flat to the ground and no gaps are visible.



8. Repeat on other side to create the complete 4-sided structure, ensuring this is square to the unit.



9. Fold the flaps down to enter to the inner strap area.



10. Loop the straps around the leg tie bars, fasten the buckle and pull to tighten each corner.



11. Raise the Quad Pod mast so the light heads clear the top of the padding when setting up (around 1.6m height)



12. Setup light heads and fold the flaps back up and secure to the unit once mast is fully deployed. Setup is now complete.

COVERING UP WHEN PADDING FITTED



1. Fold rear flap down to gain entry to the winch area and lower mast so the light heads clear the top of the padding (around 1.6m).



2. Lower front flap down to ensure light heads can stow inside padding kit and lower mast fully.



3. Secure cover back around Quad Pod and zip up on both sides.



4. Fold flaps back up and fasten using the Velcro provided to complete.

REMOVING THE PADDING



1. Lower the mast. Fold both flaps down to enter inner strap area.



2. Remove straps by pressing the buckles in each corner



3. Remove all 4 sides to padding kit by separating the velcro at each corner.





4. Undo the 3 velcro fasteners per leg and remove these from unit.



5. Remove the end caps from the leg pads.



6. Lift legs up to their storage position.



7. Ensure cover is draped over the front of the unit and secured using the ties provided. Refit the wheels.



8. Unit can now be pushed away for storage.

SETUP VIDEOS







If you have any queries with fitting please don't hesitate to contact us on 01780 758585 or e-mail sales@ritelite.co.uk

Ritelite (Systems) Ltd

Meadow Park, Bourne Road, Essendine, Stamford, Lincolnshire, PE9 4LT Tel. +44 (0) 1780 758585 | E-mail. sales@ritelite.co.uk

www.riteliteportablelighting.co.uk